



Step 1: Unpack the Strut and lay it flat on a table. If you have a 1400mm high Strut, you may need to unfold it.



Step 2: Fold the side panels of the Strut in where the Half Cuts are with two hands.



Step 3: Stand the Strut upright and fold the small locking panel in where the Half Cut is. The panel(s) should lock comfortably in place between the concave curve.



Step 4: Your Strut should now be assembled like one of the above sizes. Note: your Strut size will be automatically chosen for you according to the height of your Standee for the best fit.



Step 5: To attach the Strut to your Standee, simply hold both objects upright and align the hook and loop velcro to the allocated sections. **It is important to align the base of your Standee and Strut so they balance upright.**



Step 6: Enjoy your beautiful custom POS Standee!